

#### MTWB INSTALLATION GUIDE

#### **Description**

#### **Tools Required**

The MTWB is designed for use on the inside or outside wall of a Multi Dwelling Unit (MDU) or Multi Occupancy unit (MOU).

The unit acts as a distribution point, serving up to 16 customers from a single input cable.

Fibres from the input cable are spliced to fibres from the customer connection cables. 4 splice trays allow fibre management for up to 48 fibres.

The unit can hold a splitter and 16 pre-connectorised customer outputs.

The input cable is retained by using the GRP restraint and the cable secured with ties.

#### **Tools:**

Large Screwdriver, File, Pilers, Torque Wrench with 5mm Allen key bit

| 1 Entry Port Kit                                 | Otv 1  |
|--|--------|
| 2 Through Port Kit                               | Qty 1  |
| 3 Pull Back Cable Output Ports                   | Qty 4  |
| 4 Customer Premises cable Ports (top and bottom) | Qty 10 |
| 5 12 IFDP Installation Kit                       | Qty 1  |

#### **CONTENTS**

- 1. Box Preparation and Mounting
  - a. Cable Gland Entry for MLT & Flextube
  - b. Cable Gland Entry for Pass Through Cable
- 2. Cable Input Installation
- 3. Routing of Fibre Inputs
- 4. Routing of Fibre Outputs & Splicing
- 5. Pre-Connectorised Drop
- 6. Installation of Splitter

**Page 1 of 20** 



# 1.0 BOX PREPARATION AND MOUNTING a. CABLE GLAND ENTRY FOR MLT & FLEXTUBE

### Step 1




- Remove the cover from the MTWB box.
- Carefully knock out the cable entry port on the left-hand side of the base. Take care to support the base when doing this.

**Note**: Remove all rough edges with a file.



# 1.0 BOX PREPARATION AND MOUNTING a. CABLE GLAND ENTRY FOR MLT & FLEXTUBE

### Step 2



- Offer Base up to wall, level and mark 4 screw positions.
- Remove Base and drill marked positions using a 6mm drill bit.
- Insert wall plugs.
- Re-locate box to wall and screw into place with screws.

**Note** – Use suitable alternative wall fixing plugs if necessary to suit wall material or construction.



# 1.0 BOX PREPARATION AND MOUNTING a. CABLE GLAND ENTRY FOR MLT & FLEXTUBE

### Step 3



- Fit 'O' Seal over Cable Gland and into annular recess in hexagonal face.
- Push Cable Gland through previously knocked out cable entry port so that 'O' Seal sits against outside face of Base.
- Fit Locknut and tighten against inside face of Base to secure.



#### b. CABLE GLAND ENTRY FOR PASS THROUGH

## Step 4



- Follow steps 1-2 from Section 1 a.
- Carefully knock out the cable exit port at the top of the left-hand side of the base. Take care to support the base when doing this.
- Remove entry and exit port cut outs using suitable hacksaw.

**Note**: Remove all rough edges with a file.



#### b. CABLE GLAND ENTRY FOR PASS THROUGH

Step 5



- Fit the port cover plate to both entry and exit positions to the cable and slide into position.
- Secure pass-through cable into position using 2x cable ties at entry and exit.



#### b. CABLE GLAND ENTRY FOR PASS THROUGH

# Step 6




**Note**: A window will now be cut into the pass-through cable using approved practises and routed as preferred.



# 2.0 CABLE INPUT INSTALLATION

# Step 1




- Loosen the external gland nut and push through the cable.
- Strip cable back in accordance with approved practices.



# 2.0 CABLE INPUT INSTALLATION

#### Step 2




- For MLT Cable, carefully cut the GRP back to 50mm.
- Insert the GRP into the slot as shown and secure M4 screw until it bottoms out.
- Cable ties the cable in 2 positions as shown.
- Place a mark as shown on the loose tubes 130mm from cable butt.
- For Flextube cable, cable tie the cable in 2 positions as shown.
- Place a mark as shown on the flex tubes 130mm from cable butt.

**Page 9 of 20** 



# 2.0 CABLE INPUT INSTALLATION

# Step 3




- For MLT and Flextube Cable, Strip back to fibres in accordance with approved practices to the mark on the tubes.
- Secure the tubes into the track as shown.



# 3.0 ROUTING OF FIBRE INPUTS

## Step 1



- Starting on the bottom tray route all input fibres up the left-hand side of the track.
- Route all fibres on to tray; ensure the fibres are correctly retained in the rear hinge area.
- Store the fibres in splice tray storage area.




# 3.0 ROUTING OF FIBRE INPUTS

| St | GO TO RELEVANT CABLE OUTPUT SECTION                              |
|----|--|
| •  | If splicing to cable, see routing in Section 4.0                 |
| •  | If splicing to pre-connectorised drop see routing in Section 5.0 |
| •  | If splicing to splitter see routing in Section 6.0               |
|    |  |
|    |  |
|    |  |
|    |  |
|    |  |
|    |  |

Page 12 of 20



## Step 1



• Carefully knock out the cable entry port on the right-hand side of the base. Take care to support the base when doing this.

**Note**: Remove all rough edges with a file.




## Step 2



- Fit 'O' Seal over Cable Gland and into annular recess in hexagonal face.
- Push Cable Gland through previously knocked out cable entry port so that 'O' Seal sits against outside face of Base.
- Fit Locknut and tighten against inside face of Base to secure.




## Step 3



- Loosen the external gland nut and push through the cable.
- Strip cable back in accordance with approved practices.
- Cable ties the cable in 2 positions as shown.
- Place a mark as shown on the tubes 130mm from cable butt.
- Strip back to fibres in accordance with approved practices to the mark on the tubes.
- Secure the tubes into the track as shown.



# Step 4




- Starting on the bottom tray route all output fibres up the right-hand side of the track.
- Route all fibres on to the tray; ensure the fibres are correctly retained in the rear hinge area.
- Splice the input and output fibres in accordance with approved practises and store correctly in the splice bay and storage area of tray.



# 5.0 PRE-CONNECTORISED DROP

## Step 1




- Carefully knock out relevant patch cord entry port on the bottom of the base. Take care to support the base when doing this.
- Repeat for all drops to be connected.

**Note**: Remove all rough edges with a file.



## 5.0 PRE-CONNECTORISED DROP

#### Step 2




- Feed the cable into the grommet and push into port as shown.
- Remove dust caps and plug in connectors into the adapters.
- Cable ties the cable in 2 positions as shown.
- Plug in pigtails and route all fibres on to the tray; ensure the fibres are correctly retained in the rear hinge area.
- Splice the input and output fibres in accordance with approved practises and store correctly in the splice bay and storage area of tray.



# **6.0 INSTALLATION OF SPLITTER**

## Step 1




- Locate the splitter to be installed.
- Using the top slot beneath the fibre routing area push the splitter into place.
- Route the splitter fibres around the tracks and onto the trays in the directions as shown.



### **6.0 INSTALLATION OF SPLITTER**

#### Step 2



- Ensure the splitter is pushed to the base of the insert.
- The splitter should be securely held back behind these clips.
- Go To Section 1 cable installation and Section 2 fibre routing for splicing onto the tray.

Copyright Prysmian Group - 2022 You may not copy, reprint, or reproduce in any form the content, either wholly or in part, of this Installation Guide, without the written permission of the copyright owner. Specifications are for product as supplied by Prysmian Group: any modification or alteration afterwards of product may give different result. The information is believed to be correct at the time of issue. Prysmian four preserves the right to amend the information within this Installation Guide without prior notice. This Installation Guide may include inaccuracies, omissions of content and of information and is not contractually valid unless specifically authorised by Prysmian Group. Property of Prysmian Group UK - Uncontrolled when printed Prysmian Cables & Systems Limited, Chickenhall Lane, Eastleigh, Hampshire, SO50 6YU, United Kingdom.

PRYSMIAN HELPLINE: + 44 (0) 78161916333 connectivity.helpline@prysmiangroup.com

Page 20 of 20