

POINT OF ENTRY (POE)

Product application

This Installation Procedure details how to correctly use the POE.

The Prysmian Point of Entry (POE) is typically used in corridors. The POE allows a small cable to pass through the box and fiber to be broken and spliced or connectorized and connected to the customer cable.

Precautions and Warnings

- ! This guide is only valid for products purchased from or approved by Prysmian.
- ! During this procedure all local Health & Safety statutory regulations must be adhered to.
- ! This installation should only be carried out by suitably trained competent persons.

INSTALLATION INSTRUCTION

POINT OF ENTRY (POE)

Tools Required

Screwdriver	Needle Nose Pliers
	

Parts List

POE	Splicing Insert for up to 12 splices	Adapter Holder for an SC or LC Duplex adapter
		

INSTALLING THE POE**Step 1**

Wall mounting positions.



INSTALLATION INSTRUCTION

INSTALLING THE POE

Step 2

For fiber entrance remove the knockout from the base.



INSTALLATION INSTRUCTION

INSTALLING THE POE

Step 3

Fiber route and splicing positions.



INSTALLATION INSTRUCTION

INSTALLING THE POE**Step 4**

For more splicing positions use the Splicing Insert.



INSTALLATION INSTRUCTION

INSTALLING THE POE

Step 5

For an adapter (SC Simplex or LC Duplex) use the Adapter Insert.



INSTALLATION INSTRUCTION

INSTALLING THE POE

Step 6

Entrance for Prysmian IFSIT Cable Kit or Prysmian Raceway.



Copyright Prysmian - 2026 You may not copy, reprint, or reproduce in any form the content, either wholly or in part, of this Installation Guide, without the written permission of the copyright owner. Specifications are for product as supplied by Prysmian: any modification or alteration afterwards of product may give different result. The information is believed to be correct at the time of issue. Prysmian reserves the right to amend the information within this Installation Guide without prior notice. This Installation Guide may include inaccuracies, omissions of content and of information and is not contractually valid unless specifically authorised by Prysmian. Property of Prysmian UK - Uncontrolled when printed Prysmian Cables & Systems Limited, Chickenhall Lane, Eastleigh, Hampshire, SO50 6YU, United Kingdom.

PRYSMIAN HELPLINE: + 44 (0) 7816191633
connectivity.help@prysmian.com

INSTALLATION INSTRUCTION

Contact information

	Office	Telephone Fax	email
ASEAN	Singapore	T : +65 6898 3633 T : +65 6265 0707	sales.asean@prysmian.com
AUSTRALIA	Liverpool	T: 1300 300 304 F : 1300 300 307	sales.telecom.au@prysmian.com
CHINA	Wuxi	T : +86 510 68069518 F: +86 510 68069559	tls.china@prysmian.com
DANUBIAN	Slatina	T : +40-349-406.628 F : +40-349-433.484	customercare.romania@prysmian.com
FRANCE	Champs-Sur-Marne	T : +33 1 69 67 72 80	telecom.fr@prysmian.com
ITALIA	Milano	T: +3964493939 F: +3964499264	pqa@prysmian.com
LATAM	Sorocaba	T: +55 15 3212 6801 F: +55 15 3212 6814	sales.telecom.br@prysmian.com
MIDDLE EAST	Dubai	T : +971 4 368 8682 F : +971 4 368 8683	dubaioffice@prysmiancables-me.com
NORDICS	Malmö	T : +46 380 554 265	info.nordic@prysmian.com
NORTH AMERICA	Lexington	T : 800 669 0808	comm.cables@prysmian.com
OPGW & SPECIALS	Vilanova	T: +34 93 811 6181 F: + 34 93 811 6031	opgw@prysmian.com
RUSSIA	Moscow	T: +7 495 777 80 86 F: +7 495 777 80 89	info.ru@prysmian.com
SPAIN & AFRICA	Maliaño	T: +34 942247118 F: +34 942247114	santander.bo@prysmian.com
TURKEY	Istanbul		tpks@prysmian.com
UK	Eastleigh	T: +44 2380 295 000	sales.telecom.uk@prysmian.com